



DIY SELF-SERVICE GUIDE

HOW TO ADJUST A STRIKE PLATE ON A TWO PANEL SLIDING DOOR



Materials Required:

Phillips Head Screwdriver, Putty Knife



Difficulty:

Medium



Time Requirement:

15 minutes

INSTRUCTIONS:

To remove and adjust the strike:

1. Open the sliding door.
2. Use a putty knife to remove center silver plate (the small square in the middle).



SILVER PLATE



REMOVE PLATE

3. Use a Philips head screwdriver to remove the screws on the top and bottom of the strike. (This will allow you to loosen center screw under silver plate that will allow you to move strike up or down.)



REMOVE SCREWS



LOOSEN CENTER SCREW

4. With the screw loosened, make the strike adjustment you need, either up or down.

5. Once you are satisfied with the adjustment, tighten the screws.



MOVE UP OR DOWN TO ADJUST

To reinstall the strike:

1. Press the center silver plate back into place.
2. Close the door to check if the pressure pin engages properly and lines up in the center.



PRESS PLATE BACK IN



PRESSURE PIN

-
3. Readjust if it is not accurate by popping the center silver plate back out, loosen the screw and move the strike up or down to align.
 4. Once satisfied, pop the center silver plate back out one final time to tighten the screw completely and press the place back into place.
 5. Put the top and bottom screws back on the strike and tighten.



TIGHTEN ALL SCREWS WHEN FINISHED