

Product Care Instructions

Watch the Video

PROPER REMOVAL & REPLACEMENT OF SLIDING GLASS DOOR SCREEN

Materials Required

Phillips screwdriver

Putty knife

Safety glasses

Gloves

Safety Precautions

This activity is appropriate for individuals with an understanding of how to use simple hand tools. Remember to wear eye protection and to make sure that pets and small children are not present when performing these activities.

For questions, please contact us:

1.800.MILGARD

milgard.com

We're going to show you how to properly remove and reinstall the screen on a sliding glass door.

1. To remove the door screen, you will need to take the screen off the rollers. Find the screws at the bottom of either side of the screen. Using a Phillips screwdriver, turn the screw clockwise to raise the screen up. Continue until you see the head of the screw. Repeat this procedure on the other side. The wheel will now be in the upright position.



2. Next raise the screen and locate the wheels, the wheels are located at either end of the screen. Place the putty knife under the wheel, push in and lift. Once the wheel is up, gently slide the screen towards you. Do the same on the other side.





3. To reinstall the screen, line up the top two wheels back inside the track and push up the screen as high as it will go. Hold the screen out slightly and push the wheel up with the putty knife and slide the screen back into the track. Do the same on the other side.







Product Care Instructions

4. Before you operate the screen, the rollers must adjusted. Using a Phillips screwdriver, turn the screws counter-clockwise until you see the screen lower into the track. Repeat the same procedure on the other side.



5. Check to make sure the screen operates smoothly.