

O DIY SELF-SERVICE GUIDE

HOW TO REPLACE A SWING DOOR HANDLE



Phillips Screwdriver



Medium



10 minutes

INSTRUCTIONS:

- 1. Remove the 2 screws on the inside handle.
- 2. Once the screws are removed, the exterior handle will come out.





SCREWS

3. Pull the handle off.

- 4. Re-apply new handles doing the exterior side first, then the interior side.
- 5. Make sure to point both handles in the same horizontal direction.
- 6. Install the 2 interior screws to complete the installation.



KEEP HANDLES HORIZONTAL TO EACH OTHER

INSERT EXTERIOR HANDLE FIRST