

Product Care Instructions

Watch the Video

HOW TO REMOVE A WINDOW SCREEN

Materials Required

Safety glasses

Gloves

1. Your screen will typically have a snug fit. Press up on the top of the screen and at the same time, lift up on the screen tabs and remove the screen.





2. There are four components to the screen: Compression Spring, Frame, Mesh and Screen Tabs.





3. To reinstall the screen, slide the screen into the groove and lift the screen tabs while pressing the top.

Safety Precautions

This activity is appropriate for individuals with an understanding of how to use simple hand tools. Remember to wear eye protection and to make sure that pets and small children are not present when performing these activities.

For questions, please contact us:

1.800.MILGARD

milgard.com